



Medallion

www.medallion1.com

MoistureBlock™ .006 Film Barrier



MoistureBlock®
.006 Film Barrier

MoistureBlock is a low density Polyethylene film that can be used during the installation process with floating laminate and engineered wood floors. No need to bother with large fold-out, low quality, off-spec, construction grade films, which are bothersome and hard to use before the floor is installed.

MoistureBlock is also recommended for use with pre-attached floating wood floors in which the padding is attached to the floor during the manufacturing process. While installing a pre-attached padded floor, it is recommended to also install a moisture resistant film over concrete or any substraat where moisture is a concern.



ADVANTAGES

MoistureBlock has self sealing adhesive tape for ease of installation.



INSTALLATION INSTRUCTIONS

- Always read the flooring manufacturer's recommendations and instructions before installing the underlayment.
- Before rolling out the underlayment, be sure to sweep, vacuum, and remove all debris on the substructure.
- Fill in any significant holes, gaps or breaks that may exist on the substructure.
- Roll out the Underlayment over the substructure surface.
- Splice each roll of underlayment with a 3mm film tape, duct tape, or similar pressure-sensitive tape that meets/exceeds the water vapor transmission ratings suggested by the flooring manufacturer.
- If installing MoistureBlock Film Underlayment with Self-Sealing film edge, simply connect the rolls by removing the liner from the tape and adhere to the edge of the previous roll.
- Always be sure to connect the film rolls together with the adhesive tape evenly so that there are no gaps between the adjoining rolls of film.

2434 Polvorosa Avenue • San Leandro, CA 94577 • Phone 510-351-8104 • Fax 510-351-7480
839 F Street, Suite 100 • West Sacramento, CA 95605 • Phone 916-372-8501 • Fax 916-372-2175
645 Ahua Street • Honolulu, HI 96819 w Phone 808-836-3585 • Fax 808-834-4722

www.Medallion1.com